



NOTE: ALWAYS INSTALL PANELS FROM RIGHT TO LEFT (Looking up at ridge from eave)

| |
|-------------------------------------------------------------|
| PERMATILE ROOFING A Division of Advanced Aluminum |
| DESCRIPTION: PERMATILE SCREW FASTENING DETAIL |
| STYLE: STANDARD PERMATILE PANEL |
| FILE: SCREWPATTERN-01 |